
How It Works

Diesel Locomotive
Air Breaking
Dynamic Breaking

How Diesel Locomotives Work



Engine Turbocharger

Main Engine

Main Generator

Cab

Head-end power unit

Fuel Tank

Batteries

Cooling Fans/Radiators

Trucks

Control Stand

Coupler

Filters


Cab Seat

Air Compressor

Dynamic Brake Grid


Dynamic Brake Fan

Compressed Air Tank



Diesel gas is the energy source

How Diesel Locomotives Work



Engine Turbocharger

Main Engine

Main Generator

Cab

Head-end power unit

Fuel Tank

Batteries

Cooling Fans/Radiators

Trucks

Control Stand

Coupler

Filters

Cab Seat

Air Compressor

Dynamic Brake Grid


Dynamic Brake Fan

Compressed Air Tank



- Diesel gas is the energy source
- Gas fuels the engine

How Diesel Locomotives Work



Engine Turbocharger

Main Engine

Main Generator

Cab

Head-end power unit

Fuel Tank

Batteries

Cooling Fans/Radiators

Trucks

Control Stand

Coupler

Filters


Cab Seat

Air Compressor

Dynamic Brake Grid


Dynamic Brake Fan

Compressed Air Tank



- Diesel gas is the energy source
- Gas fuels the engine
- The engine turns the generator
- The generator produces electricity

How Diesel Locomotives Work



Engine Turbocharger
Main Engine
Main Generator
Cab
Head-end power unit
Fuel Tank
Batteries
Cooling Fans/Radiators
Trucks

Control Stand


Coupler
Filters
Cab Seat
Air Compressor
Dynamic Brake Grid
Dynamic Brake Fan
Compressed Air Tank



- Diesel gas is the energy source
- Gas fuels the engine
- The engine turns the generator
- The generator produces electricity
- The electricity turns the motors in the trucks

Air Breaking

How Diesel Locomotives Work



Engine Turbocharger

Main Engine Main Generator

Cab

Head-end power unit

Fuel Tank

Batteries

Cooling Fans/Radiators

Trucks

Control Stand

Coupler

Filters

Cab Seat

Air Compressor

Dynamic Brake Grid

Dynamic Brake Fan


Compressed Air Tank



Engine drives an air compress

Air Breaking

How Diesel Locomotives Work



Engine Turbocharger
Main Engine
Main Generator
Cab
Head-end power unit
Fuel Tank
Batteries
Cooling Fans/Radiators
Trucks


Control Stand

Coupler
Filters
Cab Seat
Air Compressor
Dynamic Brake Grid
Dynamic Brake Fan
Compressed Air Tank




- Engine drives an air compress
- Air compressor fills an air tank
- Air tank supplies pressure to every car in the train
- Air pressure keeps break shoes from touching wheels

Air Breaking



Dynamic Breaking

How Diesel Locomotives Work



Engine Turbocharger

Main Engine

Main Generator

Cab

Head-end power unit

Fuel Tank

Batteries

Cooling Fans/Radiators

Trucks

Control Stand

Coupler

Filters


Cab Seat

Air Compressor

Dynamic Brake Grid

Dynamic Brake Fan


Compressed Air Tank



- Electric is no longer routed to motors
- Traction motors act like electrical generators

Dynamic Breaking

How Diesel Locomotives Work



Engine Turbocharger
Main Engine
Main Generator
Cab
Head-end power unit
Fuel Tank
Batteries
Cooling Fans/Radiators
Trucks

Control Stand

Coupler
Filters
Cab Seat
Air Compressor


Dynamic Brake Grid

Dynamic Brake Fan
Compressed Air Tank

- Electric is no longer routed to motors
- Traction motors act like electrical generators
- Electricity turned to heat in the brake grid

Dynamic Breaking

How Diesel Locomotives Work




Engine Turbocharger
Main Engine
Main Generator
Cab
Head-end power unit
Fuel Tank
Batteries
Cooling Fans/Radiators
Trucks

Control Stand

Coupler
Filters
Cab Seat
Air Compressor
Dynamic Brake Grid
Dynamic Brake Fan
Compressed Air Tank


- Electric is no longer routed to motors
- Traction motors act like electrical generators
- Electricity turned to heat in the brake grid
- Fan removes heat from locomotive

Suspension




Steering

Radial Steering prevents track wear



Typical Trucks



Radial Steering Trucks